

Locking Engineered Hardwood with Uniclic™ Technology

Float, Direct Glue, and Fasten down Installation Instructions

Locking Engineered Hardwood Flooring can be installed over most properly prepared sub-floors and are engineered to be dimensionally stable, making them suitable for installation on all grade levels where excessive moisture conditions do not exist. We continuously make technological advancements that improve product performance or installation techniques and methods. To confirm you have the most recent installation instructions, please visit our website at www.mohawkflooring.com or contact Technical Services at 888-387-9881, Option 3



Caution: Wood Dust

Cutting, sanding or machining wood products produces **wood dust**. While wood products are not hazardous under the OSHA Hazard Communication Standard (29 CFR 1910.1200), the International Agency for Research on Cancer (IARC) and the State of California have classified **wood dust** as a human carcinogen.

Precautionary Measures: Airborne wood dust can cause respiratory, skin and eye irritation. Power tools should be equipped with a dust collector. Use an appropriate NIOSH-designated dust mask. Avoid dust contact with skin and eyes.

First Aid Measures in case of irritations: In case of irritation flush eyes with water. If needed seek medical attention. If dermatitis occurs, seek medical attention.

To request a Safety Data Sheet, call 888-387-9881, Option 3

PROPOSITION 65 WARNING: This product contains chemicals known to the state of California to cause cancer and/or reproductive harm.

WARNING! DO NOT MECHANICALLY CHIP OR PULVERIZE EXISTING RESILIENT FLOORING, BACKING, LINING FELT, ASPHALTIC "CUTBACK" ADHESIVES OR OTHER ADHESIVES.

Previously installed **resilient floor covering products** and the asphaltic or cutback adhesives used to install them may contain either **asbestos fibers** and/or **crystalline silica**. The products in this carton **DO NOT contain asbestos or crystalline silica**. Avoid creating dust. Inhalation of asbestos or crystalline dust is a cancer and respiratory tract hazard. Smoking by individuals exposed to asbestos fibers greatly increases the risk of serious bodily harm. Unless positively certain that the product is a non-asbestos containing material, you must presume it contains asbestos. Regulations may require that the material be tested to determine asbestos content and may govern the removal and disposal of material. See current edition of the Resilient Floor Covering Institute (RFCI) publication "Recommended Work Practices for Removal of Resilient Floor Coverings" for detailed information and instructions on removing all resilient covering structures.

IMPORTANT HEALTH NOTICE FOR MINNESOTA RESIDENTS ONLY: These building materials emit formaldehyde. Eye, nose, and throat irritation, headache. Nausea and a variety of asthma-like symptoms, including shortness of breath, have been reported as a result of formaldehyde exposure. Elderly persons and young children, as well as anyone with a history of asthma, allergies, or lung problems, may be at greater risk. Research is continuing on the possible long-term effects of exposure to formaldehyde. Reduced ventilation may allow formaldehyde and other contaminants to accumulate in the indoor air. High indoor temperatures and humidity raise formaldehyde levels. When a home is to be located in areas subject to extreme summer temperatures, an air-conditioning system can be used to control indoor temperature levels. Other means of controlled mechanical ventilation can be used to reduce levels of formaldehyde and other indoor air contaminants. If you have any questions regarding the health effects of formaldehyde, consult your doctor or call your local health department.

INSTALLER / OWNER RESPONSIBILITY:

It is the responsibility of the installer and owner to ensure that job site environmental, sub-floor and subsurface conditions involved meet or exceed all requirements as outlined in installation instructions prior to installation. Manufacturer declines all responsibility for product performance or installation failure due to sub-floor, substrate or environmental deficiencies or jobsite conditions.

Manufacturer requires Engineered Hardwood products to be acclimated for a minimum of 48 hours prior to installation. Acclimation allows flooring to achieve equilibrium moisture content (EMC) with the installation environment. All wood continually expands and contracts until it reaches moisture equilibrium with the environment in which it's installed.

The owner/installer assumes all responsibility for final inspection of product quality. Examine flooring for color, finish, and style **PRIOR TO INSTALLATION**. If material is unacceptable, contact the seller immediately. Wood is a natural product and contains characteristics such as variations in color, tone and graining. Flooring is manufactured in accordance with industry standards, which allows manufacturing and natural deficiency tolerances up to 5% of the total installation. Installer should work from minimum of 3 cartons at the same time to ensure good color and shade blend. The installer must use reasonable selectivity and hold out or cut off piece with deficiencies. Do not install undesirable pieces. **Flooring warranties DO NOT cover materials with visible defects once they are installed.** Installation is acceptance of product quality.

All work involving water or moisture (plumbing, masonry, painting, plastering) must be completed prior to flooring being delivered. Building envelope must be complete and exterior doors and windows installed. Exterior grading and gutter downspouts should be completed and permanent HVAC systems in operation.

Precautions should be taken to protect floors from other trade work. **Do not cover floors with plastic, red rosin, felt or wax paper or previously used cardboard. Instead use a breathable material such as clean, dry, plain uncoated cardboard or Kraft paper. Inks from printed cardboard could damage the hardwood floor.** The floor should be thoroughly cleaned before covering to remove grit and debris that would damage the finish. The floor must be completely covered to eliminate uneven ambering from exposure to UV light.

Permanent HVAC should be on and operational a minimum of 5 days and maintained between 65 – 75 degrees and a relative humidity of 35%- 55% prior to delivery, during, and after installation of the flooring for the life of the product. If HVAC is not possible at time of installation the environmental conditions must be at or near normal living conditions between 60 – 80 degrees and at the average yearly relative humidity for the area.

Building interiors are affected by two distinct humidity seasons – Heating and Non- Heating. Care should be taken to maintain humidity levels between 35-55% year round. As with all wood flooring, expansion and contraction will be minimized if the interior relative humidity is consistently maintained year round. Humidification and/or dehumidification systems may be necessary to maintain your home environment to prescribed relative humidity conditions.

Heating season – Low Humidity, Dry. All heating methods create dry, low humidity conditions. Humidifiers are recommended to prevent excessive shrinkage or gapping in wood floors due to seasonal periods of low humidity.

Non-Heating Season and Coastal or Waterfront Areas – High Humidity, Wet During the non-heating season proper humidity levels should be maintained by using an air conditioner or dehumidifier during the summer months.

Manufacturer warranties do not cover natural expansion and contraction which results in separation between planks, or damage caused by excessively low or high humidity. Seasonal gapping is not considered a manufacturing defect.

Purchase an additional 5% of flooring to allow for cuts and additional 10% if installing diagonally

WARRANTY NOTE: Installer should provide owner with one carton end label from product installed along with the pre-installation moisture content readings for warranty purposes. Owner should retain carton end label and copy of invoice with product style name and style number for their records and attach to the final page of these instructions. Owner should retain excess flooring and store in a climate controlled area for future repairs in the event flooring is damaged.

The use of stain, filler or putty for correction is considered a normal practice and a routine part of installation.

Basic Tools Needed:

Safety Glasses	NIOSH approved Dust Mask
Wood/Concrete Moisture Meter both	Broom or Vacuum
Chalk Line	Starting Row Wedges
Tapping Block	Pry Bar or Trim Puller
Tape Measure	Pencil
Jamb Saw	Miter Saw
Table Saw	Utility knife
Appropriate Adhesive Trowel	Low Adhesion Painter Tape
Coordinating stain, filler, or putty	Plastic Scraper
Mineral Spirits (odorless)	Terry Towels
Thick Felt Protectors	Pull Bar
Putty Knife	Carpenters Square

Accessories Needed:

15 lb. felt or rosin paper Performance Accessories Underlayment Flooring Adhesive
Coordinating Transition Strips or Molding Mohawk FloorCare Essentials Hardwood & Laminate Floor Cleaner

PRE-INSTALLATION & JOB SITE CONDITIONS ACCLIMATION

Do not install wood flooring until appropriate temperature and humidity conditions have been achieved. Flooring should be delivered and stored inside the HVAC controlled portion of the jobsite. Flooring should be stacked with at least a four inch (4") airspace under the cartons. Remove any and all plastic wrap that may have been used to ship the material. Make certain that the room temperature is set to normal living conditions as described above. To reduce the risk of moisture related failures, the subfloor and wood flooring must be of similar moisture content. Test the subfloor by taking a minimum of 20 moisture content readings for per 1000 square feet of subfloor using a pin type moisture meter. Average these readings and include on the data sheet on page 7 of these instructions. Likewise check the wood flooring moisture content and record on the same sheet. These moisture readings are to be left as a permanent record of testing with the homeowner. When both the subfloor and flooring are below 12% moisture content and the flooring is within 4% of the subfloor moisture the product can be installed.. Do not install the floor until these moisture conditions are met.

Note: To increase reliability, sub-floor appropriate moisture testing should be performed after the HVAC system has been in operation for a **minimum of 14 days**. Excess moisture on any flooring substrate if not identified and corrected prior to installation will cause floor covering failure. Our **Warranties DO NOT cover** any problems due to moisture levels that exceed these guidelines.

SUB-FLOOR REQUIREMENTS: ON, ABOVE, or BELOW GRADE:

These recommendations are not intended to supersede federal, state or local building codes, but as with many other interior finish products, may require modifying existing structural components for a successful installation. Hardwood flooring is not a structural component. The product warranty does not protect against loss caused by inadequate subfloors, flooring substructures or improper installation of said substructures.

Engineered Hardwood Floors may be installed over any structurally sound sub-floor that is flat, clean and dry on all grade levels.

All sub-floors should be:

CLEAN – Sub-floor must be clean and free of dirt, curing compounds, drywall mud, wax, paint, oil, sealers, adhesives and other debris. These may be removed mechanically. Do not install glued down floors over chemically cleaned substrates.

FLAT – Within 3/16" in 10' radius (5 mm in 3 m) and/or 1/8" in 6' radius (3 mm in 2 m). Sand high areas or joints. Fill low areas with a high compressive strength (min.3000 psi) Portland base compound.


DRY – Wood floor moisture should be evaluated using the guidance supplied above under the heading "Acclimation". Concrete subfloors must be cured for a minimum of 30 days. The moisture content of a concrete subfloor should be tested using a Calcium Chloride test (ASTM-F-1869 or ASTM F-710) and show no greater than 3 pounds per 1000 square feet in 24 hours or in accordance with ASTM F2170 latest version RH in-situ probe. Test results must be recorded on page 7 of these instructions and left as a permanent record of testing with the homeowner. If moisture levels exceed these limits, DO NOT INSTALL the flooring until appropriate corrections are made.

STRUCTURALLY SOUND – WOOD SUB-FLOOR: Screw down any areas that are loose or squeak. Wood panels should exhibit an adequate fastening pattern, glued/screwed or nailed as that system requires, using an acceptable nailing pattern. Typical: 6" (15 cm) along bearing edges and 12" (31 cm) along intermediate supports. Flatten edge swell as necessary. Replace any water-damaged, swollen or delaminated sub-flooring or underlayment.

Building codes establish requirements for structural support components of flooring systems which may not provide adequate rigidity and support for proper installation and performance of a hardwood floor. Whenever possible, install flooring perpendicular to the floor joists for maximum stability.

NOTE: When joist spacing exceeds the traditional 16 on center, manufacturer recommends you apply a thin bead of Performance Accessories Tongue & Groove D3 glue to the bottom side of the groove to lock the tongue and groove profile in place. This will reduce the potential for movement of the tongue and groove, which may contribute to squeaking or crackle. When using this method of installation, you may continue to choose to staple or nail down the hardwood depending on your preference. Using a D3 T&G glue with the staple reduces movement as the sub-floor deflects.

NOTE: Basements and crawl spaces must be dry. Use of a 6 mil black polyethylene membrane is required to cover 100% of the crawl space earth. Crawl space clearance from ground to underside of joist should be no less than 18" and perimeter vent spacing should be equal to 1.5% of the total square footage of the crawl space area to provide cross ventilation.



STRUCTURALLY SOUND – CONCRETE SUB-FLOOR: Concrete substrate should be at least 30 days old constructed in accordance with ASTM E1745. Level substrate and fill all cracks, holes and low spots with a polymer modified Portland cement patch or leveling compound. Burnished or steel troweled concrete substrates must be inspected for porosity by placing a few drops of water on the surface. If the water is not absorbed within 3 minutes, the substrate should be considered non-porous. Abrade the surface with 30-grit sandpaper until porosity is achieved. Glued down floors may be applied to concrete with a rating of 3000 psi or greater. Glued down application over lightweight concrete (less than 3000 psi) is not permissible.

Wood Sub-floors

Approved underlayment floor panels should meet or exceed the following:

- **Plywood:** Must be minimum CDX grade (exposure 1) and conform to US Voluntary Product Standard PS1 performance standard or Canadian performance standard CAN/CSA 0325-0-92.
- **Oriented Strand Board (OSB):** Must Conform to US Voluntary Product Standard PS2 or Canadian performance standard CAN/CSA 0325-0-92. The panels must be tongue and groove and installed sealed side down.
- Floor joist/truss spacing will determine the minimum acceptable thickness of the subfloor panels. Joist/truss spacing of 16" o/c or less for single panel subflooring requires a minimum 5/8" (19/32", 15.1 mm) CDX (Exposure 1) 4'X8' subfloor panels. Joist/truss spacing of greater than 16", up to 19.2" (488mm) o/c, requires a minimum nominal ¾" (23/32", 18.3 mm) T&G CDX (Exposure 1) Plywood or OSB 4'X8' subfloor panels, glued and mechanically fastened. Floor systems with

joists/truss spaced greater than 19.2" (488mm) o/c up to a maximum of 24" (610mm) require minimum 7/8" T&G CDX (Exposure 1) Plywood or OSB 4'X8' subfloor panels, glued and mechanically fastened. Installation over joists spans greater than 24" is not recommended. For installation over joists spans greater than 24" on center, consult NWFA for panel thickness guidance.

- **Particleboard:** Must be a minimum 40-lb. density, stamped underlayment grade and 3/4" (19 mm) thick. (**Floating installation only**)

Solid Wood Sub-floors - Direct Glue or Staple Down Applications

- Minimum 3/4" (19 mm) thick with a maximum width of 6" (15 cm) installed at a 45° angle to the floor joists.
- Group 1 dense softwood (Pine, Larch, Douglas fir, etc.) No. 2 common, kiln dried with all board ends bearing on joists.
- For direct glue-down applications add 3/8" (9.5 mm) approved floor panel underlayment.

Existing Wood Flooring – Direct Glue or Staple Down Applications

- Existing engineered flooring must be well bonded/fastened. When gluing over existing wood flooring, the surface finish must be abraded or removed to allow adequate adhesive bond.
- Existing solid hardwood flooring that exceeds 6" (15 mm) in width must be covered with 3/8" (9.5 mm) approved underlayment and fastened as required.
- **Do not install over solid or engineered flooring attached directly to concrete.**

Wood sub-floors should be well nailed or secured with screws. Nails should be ring shank and screws need to be counter sunk. The wood sub-floor needs to be structurally sound (meaning sub-floors without loose boards, vinyl or tile). If sub-floor panels are a single layer, less than ¾" thick, add another single cross layer for strength and stability (minimum 3/8").

Underlayment floor panels must be installed sealed side down. When used as a sub-floor, allow 1/8" (3 mm) expansion space between each panel. If spacing is inadequate, cut in with a circular saw. Do not cut an expansion space on tongue and groove panels. When installing parallel to the floor joists it may be necessary to increase rigidity of the structural sub-floor system by installing an additional minimum of 3/8" (9.5 mm) approved underlayment floor panel.

Radiant Heat Sub-floors

Performance Core flooring products are **not recommended** for installation over radiant heat floor systems.

For Multi-Layered Core products, it is important to follow these guidelines strictly. Failure to follow these guidelines may produce unsatisfactory results.

Only multi-layered core products are approved for radiant heat systems.

Before installing hardwood over radiant heat subfloors, determine if the radiant heat system is rated to be compatible with hardwood flooring. It is highly recommended the radiant heat system be designed specifically to accept hardwood flooring. **Radiant heat systems designed for floor coverings with a higher resistance to heat transfer such as carpet will damage wood flooring.** Single heat circuit systems designed for use with multiple floor covering products must be adjusted to work at temperatures suitable for hardwood flooring. **Use of an in floor temperature sensor as well as a separate thermostat for the individual room is required. An outdoor temperature sensor should be used to adjust water temperature according to anticipated heat loss.**

Note: When radiant heat is installed in concrete, mortar beds, or gypsum cement, it is very important to operate the radiant heat system until these are completely dry before you install your hardwood flooring on top. This may take several weeks. Also operate the HVAC system to allow humidity levels in the area to stabilize (35- 55% RH) for the area in which the hardwood floor will be installed. Allow hardwood to acclimate to this humidity level before installation. This will minimize dimensional changes due to moisture.

Before installing over a radiant heat floor turn off heat and wait until the floor has reached room temperature (70°-75°F). After installing the floor, gradually return the heat in 5 degree increments. **CAUTION: The floor surface must never exceed 85°F.**

Concrete Sub-floor

Lightweight concrete

Gluing of Engineered wood flooring is not recommended over lightweight concrete subfloors. To test for lightweight or acoustical concrete, scrape a coin or key across the surface of the sub-floor. If the surface powders easily or has a dry density of 100 pounds or less per cubic foot, the Performance Core Engineered flooring should not be installed.

Sub-floors other than wood or concrete:

Perimeter glued resilient vinyl and rubber tiles are unacceptable underlays and must be removed. Terrazzo, Vinyl, Resilient Tile, Cork and Linoleum or hard surfaces that are dry, structurally sound and level are suitable as a sub-floor. As above, the surface must be sound, tight and free of paint, oil, existing adhesives, wax, grease and dirt. Terrazzo and ceramic tile must be scuffed to assure adhesion.

Warning! Do not sand existing resilient tile, sheet flooring, backing, or felt linings. These products may contain asbestos fibers that are not readily identifiable. Inhalation of asbestos dust can cause asbestos or other serious bodily harm. Check with local, state and federal laws for handling hazardous material before attempting the removal of these floors.

Floating Instructions - Uniclic® Locking Engineered Hardwood

FLOATING INSTALLATION

PREPARATION:

Undercut Door Casings: Undercut all door casings 1/16" higher than the thickness of the flooring materials being installed. To do this, use a scrap piece of flooring as a guide. Lay it on the substrate and cut the casing with a handsaw or use a power jamb saw set at the correct height. Remove all moldings and wall-base, and undercut all door casings.



Underlayment:

Use Performance Accessory Underlays or equivalent with equal or better specifications. Underlayment requirements are very critical to a floating installation. Excessive pad compression or compaction is a common cause of seam failure. Lay the underlayment on the floor with the moisture barrier facing up. The direction of the underlayment should be parallel to the direction of the floor being installed. For the first row of flooring the underlayment should be placed so that approximately 1 inch overlaps onto all perpendicular walls. Place the following row next to the first row on top of the lower moisture barrier overlap. Remove the adhesive strip and fold back the upper overlap on the second row. Make sure the underlayment fits together tightly (don't leave gaps). On the last row, place the underlayment 1 inch up the wall. To join rolls on the short side of the underlayment, use a moisture resistant tape to connect the 2 pieces so water cannot penetrate the underlayment.


Expansion Space:

An expansion space of at least 3/8 inch must be maintained around the perimeter of the room, all pipes, counters, cabinets, fireplace hearths, doorframes and any other fixed vertical objects in the room. **Doorway or archways 48 inches or less and rooms larger than a 26 X 33 are required to have a T-Molding.**

Row One:

Plank 1 should begin in the left hand corner of the room. Spacing around the wall perimeter equal to the plank thickness can be maintained by using wood wedges. The planks are laid with the tongue side facing the wall. The first row starts with a full length board and working from left to right. Overlap the end joint of the board being installed onto the board previously installed. Place each plank firmly against the wood wedges. After setting the first row and making sure you are against a firm starting point, lay out three to four rows before starting to install. As shown below in Figure 1, Plank 2 end joint overlaps the end joint of Plank 1. Lay the rest, plank after plank, in this manner until you have completed the first row. Cut the last plank accordingly. Ensure that this first row is straight using the wedges to maintain proper expansion space from the wall.

Figure 1



Most often walls are not structurally square. Planks in the first row may need to be scribed and cut to contour the first row with the wall and to allow for 3/8" expansion. Allow 3/8" expansion space at all vertical obstructions. Use 3/8" wood wedges or short cut 3/8" pieces of the floor against the wall to hold planks true to spacing. It is important that the planks follow the wall. Scribing is used if the wall is not straight. First, mark the plank with a scribing tool or other tool that will allow you to follow the shape of the wall and then cut it lengthwise to follow the line.

Figure 2



Row Two:

When possible use leftover plank from the first row to begin the second row. The leftover piece from the first row should be considered for this starter piece to minimize waste. Initial layout of material will allow you to check your end seams to ensure they are not too close. End joints on adjoining rows should be offset by no less than 6". Align this plank and lock the side into place against the first plank in row 1. The next plank is aligned with the end joint first into the previous plank in row 2. The side of plank is then tapped lightly against the previously laid row. Continue laying in this way across the entire row. Press in the row of planks with a light pressure on the long side. The planks lock into each other. The Uniclic Tapping Block- square

edge tapping block is needed to aid in the connection of the planks locking system-on the long side. The planks are now laid row after row in this sequence.

Row Three and Remaining Rows: Move rows if necessary to ensure that you are not showing any undesirable joint patterns. (Figure 3A) The rest of the row's end joints should be random throughout the floor. (Figure 3B) Your first three rows are staggered ensuring that offset of previous row with end joints are no closer than 6" from one another. When the planks are being tapped in place, a non-random pyramid or stair step pattern is used to ensure the planks remain engaged through the force of the tapping. The numbered process is shown in Figure 1.




Figure 3A




Figure 3B

Tapping the planks together

When tapping the planks together the following process works best: 1) Using the Uniclic Tapping Block, lightly tap each piece until the plank lays flat. **DO NOT FORCE THE PLANKS DOWN FLAT.** Start tapping in the plank at the opposite end along the length working from left to right, making sure the plank fully engages as you progress down the length as shown below in Figure 4



Figure 4

When end joint is slid into place on the preceding plank, raise the plank now being installed to an approximate 45° angle while setting the side joint into place. (Figure 5)




Figure 5

When you have the plank in place, lower the plank while taping it until plank is lying flat and locked in place. (Figure 6)

The initial rows, when you are not against a firm starting structure, may seem more difficult to engage than the following rows.



Figure 6

The Uniclic Tapping Block-square edge tapping block is needed to distribute equal force across the tongue without any damage. (Figure 4 and Figure 5)) For best results, slide the tapping block along the sub-floor and row, tapping lightly with a hammer, while using tapping strokes to engage the locking system. If the planks will not go together, check to see if the planks are moving against the wall with the strikes. If so, adjust shims to firm up or use the screw down starter row method.




Figure 7

The last row may require the use of a "pullbar" as shown to secure the click joint



Figure 8

Installer's Responsibility:

Warranty for separation of planks is the responsibility of the installer.

Direct Glue Installation: Make sure the floor covering materials are well bonded to the sub-floor/underlayment with full spread adhesive and no more than two layers thick, not to exceed 3/16" (5 mm). With approved wood/wood composite sub-floors, if vinyl or tiles are loose, broken, or in poor condition, install a 3/8" (9.5 mm) approved sub-floor panel directly over the flooring materials. Clean the flooring materials as necessary to remove waxes, sealers or cleaning residues to allow a good adhesive bond. Cork floor sealers and surface treatments must be removed. Always perform a bond test prior to beginning direct glue installation.

Adhesive Selection:

Acceptable sub-floor moisture condition requirements will vary dependent upon your selection of M1000, M808 or M908/WUA2 adhesive. Adhesive moisture requirements are not interchangeable between adhesives and vary dependent upon the sub-floor type and conditions. The sub-floor moisture requirement and test for each adhesive is outlined in the following:

M1000 ULTRATACK ADVANCED 3 IN 1 ADHESIVE (CONCRETE ONLY):

- Up to 95% RH Levels in Concrete Using In-situ Probes in accordance with the latest version of ASTM F 2170.
- A pH test up to 11.0.
- Test for sealers and curing compounds.

M808 TRI-POLYMER ADHESIVE (WOOD & CONCRETE SUB-FLOOR):

Wood:

- Wood substrates should test less than 12% using a wood moisture meter.

Concrete:

- Up to 85% RH Levels in Concrete Using In-situ Probes in accordance with the latest version of ASTM F 2170.
- pH test results must be between 7.0 - 9.0.
- Test for sealers and curing compounds.

M908/WUA2 PRO-TACK URETHANE ADHESIVE:

Wood:

- Wood substrates should test less than 12% using a wood moisture meter.

Concrete:

- Less than 3 lbs/1000 sq. ft./24 hrs. Calcium Chloride Test (ASTM F1869)
- Up to 75% RH Levels in Concrete Using In-situ Probes in accordance with the latest version of ASTM F 2170.
- Test for sealers and curing compounds

To correct any sub-floor conditions concerning moisture, either wait until the sub-floor dries to meet specifications or use an appropriate moisture barrier. For more information concerning moisture conditions, contact Technical Service Department at 888-387-9881 Option 3.

DO NOT INSTALL FLOORING IF MOISTURE TESTS RESULTS EXCEED RECOMMENDED LIMITS.

- Plan your layout and determine the direction of the installation in the room. Planks installed parallel to windows accent the hardwood best.
- Blending of Cartons: To achieve a uniform installation appearance, preselect and set aside hardwood planks that blend best with all trims and moldings. Install these planks next to best blended moldings.
- Remove all wall mounted moldings such as base and quarter round.
- Floor should be installed blending planks from several cartons to ensure good color and shade mixture throughout the installation.
- Be attentive to staggering the ends of the boards at least 4"-6" (10-15 cm), in adjacent rows.

NOTE: USE OF A RUBBER MALLET TO INSTALL FLOORING IS NOT RECOMMENDED AS STRIKING THE SURFACE WITH A RUBBER MALLET MAY CAUSE IRREPARABLE DAMAGE TO THE PLANK.

GLUE DOWN INSTALLATION GUIDELINES

Direct Glue Installation. Use Performance Accessories Adhesives and Sealers or products that meet or exceed manufacturer's adhesive and sealer specifications as specified below. Refer to container labels for specifics on trowel size, etc.

Select adhesive based on Adhesive Selection Guidelines provided above.

CONCRETE: If an excess sub-floor moisture situation exists, it is required that M1000 Ultratack Advanced 3 in 1 Adhesive be applied using the provided clip-on trowel. Use of these or products with equal or greater specifications are necessary for warranty compliance.

Locking Engineered Flooring – Moisture/Sound Suppression Method Application (trowel clip on top of bucket):

M1000 Ultratack Advanced 3 in 1 Adhesive

A low VOC saline terminated polymer adhesive designed for use on or above grade concrete substrates where excessive moisture may be present.

For concrete substrates with RH readings up to 95% use the Clip-On Trowel Blade provided and attached to the top of each pail. Clip on trowel blade must be replaced with each pail of adhesive used or more frequently as wear dictates. Floor pH must not exceed 11. ----- Approximate coverage 35 square ft. per gallon.

For concrete substrates with RH readings less than 80% use a 3/16" x 1/4" x 1/2" Flat V Notch Trowel. Trowel should be replaced every 3000 square feet or sooner if excessively worn. Floor pH must not exceed 11. ----- Approximate coverage 55 square ft. per gallon.

*Coverage is based on application to a clean, smooth concrete substrate; therefore, application rate may vary depending on substrate conditions.

USES:

- For protection from concrete moisture up to 95% RH
- Sound reduction in multi-story buildings
- Crack suppression for in plane cracks up to 1/8" wide

Important: Only the above specified trowels and application methods are to be used with this adhesive; otherwise, the product performance warranties and liabilities will be made void. Use of these or products with equal or greater specifications are necessary for warranty compliance.

M808 Tri-Polymer Adhesive:

A high tri-polymer formula adhesive for the installation of engineered wood flooring over a variety of properly prepared substrates including: concrete, APA approved sub-floor panels, sheet vinyl, VCT and clean abraded terrazzo.

Wood substrates should test less than 12% using a pin moisture meter.

Use a 3/16" x 1/4" x 1/2" Flat V Notch Trowel. Trowel should be replaced every 3000 square feet or sooner as wear dictates. ----- Approximate coverage is 200-220 square ft. per 4 gallons.

Concrete substrates should test less than 85% RH use a 3/16" x 1/4" x 1/2" Flat V Notch Trowel. Trowel should be replaced every 3000 square feet or sooner as wear dictates. ----- Approximate coverage is 200-220 square ft per 4 gallons.

*Coverage is based on application to a clean, smooth concrete substrate; therefore, application rate may vary depending on substrate conditions

USES:

- For protection from concrete moisture up to 85% RH
- Will not etch the finish on a pre-finished board
- May be used on properly prepared concrete or wood substrates.

Important: Only the above specified trowels and application methods are to be used with this adhesive; otherwise, the product performance warranties and liabilities will be made void.

M908/WUA2 Pro Tack Adhesive

A trowel applied moisture curing urethane adhesive for the installation of glue down flooring installations over concrete and wood substrates.

TYPICAL TROWEL AND APPROXIMATE COVERAGE*

3/16" x 1/4" x 1/2" V-notch trowel: 50 to 65 square ft. per gallon.

*Coverage is based on application to a clean, smooth concrete substrate; therefore, application rate may vary depending on substrate conditions

NOTE: Do not apply over self-stick tile, sheet vinyl, old adhesives, metal, linoleum, laminate, particleboard or strip wood sub-floors without first covering with an approved wood or wood composite underlayment. Air temperature must be between 50 F and 100 F for applying ProTack M908/WUA2 Urethane Adhesive.

- Product must be used in its entirety when opened. Lid cannot be re-sealed.
- Temperature and humidity will affect the curing time. The higher the temperature and humidity, the faster the cure.

APPLICATION

1. Regulate temperature and humidity 72 hours before, during and after installation.
2. Spread adhesive using recommended trowel, ensuring 95 – 100% adhesive contact.

Wet-lay method: Press flooring firmly into adhesive immediately after troweling.

Walk-on method: Press flooring firmly into adhesive after it has developed its initial grab (typically, after 15 to 20 minutes).

3. Remove any adhesive smudges or drops immediately as adhesive is very difficult to remove once allowed to dry. Clean tools while adhesive is fresh using a urethane adhesive remover or mineral spirits.

4. Avoid light/regular foot traffic for at least 12 hours. Avoid heavy foot traffic for at least 24 hours.

Use clean white terry cloth towels with mineral spirits to clean as you go. It is easy and convenient to use. Adhesive that has cured on the surface of the flooring can be difficult to remove.

Getting Started Direct Glue:

There are two ways to install when using a moisture cured urethane wood flooring adhesive (wet lay meaning to lay directly into wet adhesive and dry-lay method meaning to allow the adhesive to flash or to tack up.)



Caution: Whether you choose to install using the dry or wet method, follow all guidelines set by the adhesive manufacturer as well as the flooring manufacturer. By not adhering to the guidelines you can void your flooring warranties.

General Information for Glue-Down Installations

1. Use cement-based patch, skim coat leveling products to correct substrate imperfections.
2. Regulate temperature and humidity 72 hours before, during and after installation.
3. At least 48 hours before installation, place cartons of wood flooring in the installation area.
4. Install and secure starter row.
5. Spread adhesive using recommended trowel, ensuring 95 to 100% adhesive contact. Wet Lay method: press flooring firmly into adhesive immediately after troweling. After the flooring is place, roll the entire installation with a 75 lb. smooth roller.
6. Inspect the installation and remove any adhesive smudges or drops immediately using mineral spirits. **NOTE:** Urethane adhesive is very difficult to remove once dry and cured. Make every effort to prevent adhesive from getting on the flooring surface. For best results, keep a urethane adhesive cleaner or mineral spirits nearby to remove any adhesive smudges or drops during installation.
7. Clean tools while adhesive is fresh using a urethane adhesive cleaner or mineral spirits.
8. Avoid light/regular traffic for at least 12 hours. Avoid heavy traffic for at least 24 hours.
9. See adhesive manufacture guidelines for OPEN TIME on the adhesive container.
10. Proper ventilation within the room must be provided. An electric fan is helpful.

Step 1 (Wet Lay Method)

Select a starter wall. It is recommended to start the installation along an exterior wall. It's more likely to be straight and square with the room. Measure out from the wall the width of two planks plus 3/8" expansion and mark each end of the room and snap your chalk line.



Step 2

Spread adhesive from the chalk line to the starter wall using the recommended trowel size. It is important to use the correct trowel at a 45° to get the proper spread of adhesive applied to the sub-floor, which will produce a proper and permanent bond. Improper bonding can cause loose or hollow spots.

Note: Change the trowel every 2000 to 3000 square feet (or sooner as needed) due to wear down of the dimples. This assures you always get the proper spread of adhesive.

Step 3

Install the first row of starter planks with the tongue facing the starter wall and secure into position. Alignment is critical and can be achieved by securing a straight edge along the chalk line (2x4's work well), or by top nailing the first row with finishing nails (wood sub-floor), or adjustable spacers (concrete sub-floor). This prevents slippage of the planks that can cause misalignment.

Note: The planks along the wall may have to be scribed and cut to fit in order to maintain a consistent expansion space since most walls are not straight. Try to maintain at least 2" on the scribed plank.

Step 4

Once the starter rows are secure spread 2 1/2 to 3 feet of adhesive the length of the room. (Never lay more adhesive than can be covered in approximately 1 hr.) Place tongue into groove of plank or strips and press firmly into adhesive. Never slide planks or strips through adhesive. Use Uniclic Tapping Block to fit planks snug together at side and butt ends. Clean any adhesive off the surface before it cures using clean terry cloth towels and mineral spirits.

Note: Never work on top of the flooring when installing. If you must work on top of the newly laid flooring use a kneeling board.

Secure your starter rows with a straight edge (2x4's). Once the remainder of the floor has been installed, go back to the beginning and remove the straight edges and spread adhesive on the remainder of the open sub-floor. Remember planks closest to the wall may have to be scribed and cut to fit due to irregularities along the wall. **When using Mohawk's Pro-Tack M908/WUA2 adhesive it is not necessary to roll the floor.**

Clean Up

Use clean white terry cloth towels to clean as you go along with mineral spirits. It is easy and convenient to use. Adhesive that has cured on the surface of the flooring can be difficult to remove.

Light foot traffic is allowed after 12 hours but wait 24 hours after installation to remove the Low Adhesion Delicate Surface Painters Tape. Once the tape is removed clean any adhesive residue left from the tape using mineral spirits on a clean white terry towel.

Clean Up

Use clean white terry cloth towels to clean as you go along with mineral spirits. It is easy and convenient to use. Adhesive that has cured on the surface of the flooring can be difficult to remove. Measures should be taken to protect floors from other trade work.

Final Touches

Trim excess underlayment (floating installation only) and install or re-install any transition pieces, reducer strips, T-moldings, thresholds, bases and/or quarter round moldings. Trims and moldings should be nailed into the wall, not the floor. Install the proper trim molding at the doorways to achieve

the transition and along the walls to cover the edges of any gaps along the wall due to irregularity.

Complete the job by using the wood filler that coordinates with the installed engineered flooring for minor corrections or areas where brad nails were used in the trim or the flooring. Clean the finished floor with Performance Accessories Cleaner.

To prevent surface damage, avoid rolling heavy furniture and appliances on the floor. Use plywood or appliance lifts if necessary. Use protective castors/caster cups or felt pads on the legs of furniture to prevent damage to the flooring.

If the floor is to be covered, the floor should be thoroughly cleaned prior to covering to prevent grit damage to the finish. Do not cover with plastic, red rosin, felt or wax paper or previously used cardboard. Instead use a breathable material such as clean, dry, plain uncoated cardboard or Kraft paper. Inks from printed cardboard could damage the hardwood floor.

A common reinforced builder's paper is a good choice. Any covering should be taped, using a low-adhesion tape, to base or shoe moldings. Avoid taping to finished flooring. When taping paper or sheets together, tape them to each other, not to the floor. The floor must be completely covered to eliminate uneven ambering from exposure to UV light.

Fasten Down Instructions - Uniclic® Locking

Engineered Hardwood – Uniclic® Locking Engineered Hardwood may be mechanically fastened to the floor using Flooring Cleats only. Staples Are Not Recommended.

- The recommended floor nailer is a Powernail Model 2000, 20 gage, L-cleat, pneumatic nailer.
- Cleats must be placed into the locking portion on the groove side edge of the plank as shown below.



- Adjust the nailer for proper cleat placement.
- Adjust air pressure to 70 psi to start then adjust air pressure accordingly to get the proper depth.
- Uniclic® Locking Engineered Hardwood Engineered hardwood floors may be installed over wood sub-floors (with the exception of Luan, Parquet or Masonite) using **CLEATS ONLY**. Flooring staples are not recommended. When installing engineered wood planks it is necessary to use the proper type of flooring nailer made for, or properly adjusted to, the thickness of the engineered wood flooring that is being installed.
- **Note:** In addition to the ground cover in the crawlspace, a 15lb felt or rosin paper **must** be installed over the sub-floor prior to the installation of the engineered wood flooring in order to reduce squeaks and noises created by the opposing floors.

Layout the job

- Measure out from the ends of your starting wall the width of the plank plus 3/8" for expansion and mark both ends. Where possible lay the flooring at 90° angles to the floor joists. Make a chalk line along the starting wall using the marks you made.
- **Beginning installation**
Note: Expansion space is required along the perimeter of room(s) of intended installation; expansion space is dictated by the thickness of the product, for example, 3/8" thick floor requires 3/8" expansion space, 1/2" thick floor requires 1/2" expansion space.
- Place the planks with the tongue facing the wall with the groove along your chalk line. Use brads or small finishing nails to secure the first starter row along the wall edge 1" to 2" from the ends and every 4" to 6" along the side. Counter sink the nails and fill with the wood filler that blends with the flooring installed. Place the nails in a dark grain spot in the board. The base or shoe molding will cover the nails when installed after completion of the installation.
- Blind nail at a 45 degree angle through the tongues. It will be easier IF HOLES ARE PRE-DRILLED IN THE TONGUES. Nail 1" to 2" from the ends and every 4" to 6" along the sides. It will be necessary to blind nail the next 2 rows. A brad nailer with 1" to 1-3/8" brads can also be used to blind nail and no pre-drilling is needed. Continue the installation using an engineered wood-flooring nailer, using recommended cleats. Fasten flooring 1" to 2" from ends and every 4" to 6" along the edge grooves as shown.
- **Final Touches**
Install the proper trim molding at the doorways to achieve the transition and along the walls to cover the edges of any gaps along the wall due to irregularity. Complete the job by using the wood filler that coordinates with the installed engineered flooring to fill any gapping along the joints or areas where brad nails were used in the trim or the flooring. Clean the finished floor with Performance Accessories Cleaner.

MAINTENANCE

Performance Core Engineered Hardwood Floors are very easily maintained. No wax, no mess.

The best way to care for your new floor is to schedule routine maintenance which includes sweeping the entire floor at least once a week to remove dirt and debris that may scratch the floor. High traffic areas such as entrances, doorways, and traffic lanes will require cleaning more frequently depending upon the amount of concentrated foot traffic. Following these easy steps is the key to keeping your new floor looking beautiful for years to come.

STEP ONE:

Routinely sweep your floor with a soft bristle broom or use a vacuum designed for use on hardwood floors.*

*Warning: Vacuums with a beater bar, power rotary brush head or any steam cleaning device can damage a wood floor and should never be used.

STEP TWO:

Apply Performance Accessories Cleaner to a terry cloth or micro fiber mop; do not spray directly onto the floor. Use a back and forth motion with the mop. When the terry cloth or micro fiber cover becomes soiled, simply replace it with a clean one. Cleaning the floor with a soiled cover could cause streaking. The covers are re-usable so simply throw the cover in the wash and dry it as you would any towel. **DO NOT USE FABRIC SOFTENER** when washing terry cloth or micro fiber covers.

Tips & Warnings:

- Sweep regularly with a soft bristle broom
- Remove spills promptly and use Performance Accessories Cleaner.
- Use felt protectors under heavy pieces of furniture and chairs.
- Use protective mats at all exterior entrances.
- Never use rubber or latex backed rugs on your floor. We recommend the use of Mohawk Home® rugs and non-slip rug pads. Rug pads should extend all the way to the edges of the rug to work properly. Regularly clean under rugs and rug pads.
- Spiked heels or shoes in need of repair can severely damage floor.
- Replace hard plastic, metal castors, or wheels on furniture with soft rubber castors or by using a protective mat under the castors.


- Never wet or damp mop your floors.
- Never use steam cleaners on your floor. This will force moisture into the finish and cause damage to your floor
- Never use oil soaps, wax, liquid or other household products to clean your floor.
- Keep pet nails trimmed as recommended by your veterinarian.
- Protect your floor when using a clean, soft-rubber tired dolly for moving furniture or appliances.
- Use protective window coverings to protect hardwood floors from excessive heat during periods of direct sunlight.

Hardwood flooring will scratch and dent

With today's active lifestyles it is important to note that hardwood flooring can, and will, scratch and dent. See Tips & Warnings for protecting your hardwood floor. In order to prevent excessive abuse the use of strategically placed mats and area rugs as well as floor protectors on chair and table legs are a must.

Transition Mats

Transition Mats should be used at all exterior entrances to minimize tracked in soil and reduce moisture during inclement weather. Ideally, the purchase of two sets of transition mats for each exterior entrance will allow a fresh one to replace the soiled one weekly during routine cleaning. This will prevent the transition mat from becoming a soil source.



Hardwoods react to sunlight

Hardwood contains certain types of acids in their cellular structure. With exposure to sunlight these acids begin to amber. The color change is referred to as patina. The wood will reach its own natural warmth and patina level and stop ambering. The amount of patina is directly related to the species, amount of acids and the level of sunlight. The entire floor will reach the same patina level over time. This is often noticed after a rug is removed and the floor is noticeably different in color underneath. If you remove the rug and expose the entire floor to the same amount of light, it will even out over time and become uniform in color.

WARRANTY

Manufacturer warrants that the factory applied finish will not wear through or will not lack finish adhesion as a result of normal use. Additional structural warranty and moisture warranty may be applicable to this engineered hardwood. See product sample or your retailer for specific details and duration of warranty.

Pre-installation Sub-floor Moisture Testing: Installer should use this section to record pre-installation moisture content readings. This completed form along with at least one carton end label and these floor care maintenance instructions should be provided to the owner for their records.

Wood Sub-floor		
Date:		
Installation Company:		
Moisture readings taken by:		
Moisture Content:	<input type="checkbox"/> % Average Moisture Content of Sub-floor <input type="checkbox"/> % Average Moisture Content of Hardwood <input type="checkbox"/> % Difference between sub-floor & flooring	
Concrete Sub-floor		
Date:		
Company performing concrete moisture readings:		
Moisture readings taken by:		
Test Method Used:	<input type="checkbox"/> Calcium Chloride (ASTM F1869) <input type="checkbox"/> RH (ASTM F2170-02)1869 <input type="checkbox"/> Electronic Meter	
Moisture Readings:		